

## **Decal Application Instructions**

In all cases, the application surface must be clean and free of any dirt, grease, oil, wax, dust, gum or foreign matter. Household and/or available commercial cleansers or cleaning solvents can be used to remove contaminants from the application surface. After cleaning, the surface should be rinsed with clean, warm water and dried with a clean, lint free soft cloth.

### **Application Method**

#### **Wet Application – Decals over 12”x12” or smaller decals of special die cut shapes.**

1. Clean and dry application surface.
2. Spray or use sponge to wet application surface with a wetting solution. This will allow for accurate positioning of decal.
3. Remove release liner from decal. If decal is large, place the decal face down on a flat surface to remove liner. Spray or sponge wetting solution onto the decal.
4. Position decal onto the moistened surface. Carefully use your hand to remove excess moisture and air bubbles. Work from the center of the decal to the outside edges using steady pressure.
5. Carefully wipe newly applied decal to remove residual moisture so that decal is dry.
6. If air bubbles occur, puncture with pin or needle and smooth down.

**Note:** Using a wetting solution with emulsion adhesives will cause adhesive to become milky or hazy. This is caused by water mixing into the adhesive of the film. This normally clears up in 24-48 hours under normal conditions.

### **“Mirror” Application**

Once the decal is up, you will then apply the “mirror”.

1. Remove liner from both strips of tape on back of mirror.
2. Position “mirror” with tape over printed mirror.
3. Lightly apply pressure to area above tape.
4. Clean mirror with damp cloth.